


## Tool Instruction Pressure Test Adapter

4328619R1

---

Tool Number: EN-46091-25



0000433608

**Figure 1. EN-46091-25 — Pressure Test Adapter**

### Purpose

EN-46191-25 is an essential tool used to block the exhaust system when pressure testing the air management system. The Pressure Test Adapter is inserted between the Diesel Oxidation Catalyst and the Diesel Particulate Filter.

## Application(s)

International® 6.6 Engine

Additional Engines / Vehicle Applications May Apply



**GOVERNMENT REGULATION:** Engine fluids (oil, fuel, and coolant) may be a hazard to human health and the environment. Handle all fluids and other contaminated materials (such as filters or rags) in accordance with applicable regulations. Recycle or dispose of engine fluids, filters, and other contaminated materials according to applicable regulations.



**WARNING:** To prevent personal injury and / or death, read all safety instructions in the “Safety Information” section of the *Engine Service Manual* or *Engine Diagnostic Manual*.



**WARNING:** To prevent property damage, personal injury, and / or death, park vehicle on hard flat surface, turn the engine off, set the parking brake, and install wheel chocks to prevent the vehicle from moving in either direction.





**WARNING:** To prevent personal injury and / or death, always wear safe eye protection when performing vehicle maintenance.



**WARNING:** To prevent property damage, personal injury, and / or death, inspect tool for wear / damage prior to use. Replace any worn or damaged components as necessary.

## Tool Contents

Table 1

Image	Tool Number	Qty	Description
 0000433607	EN-46091-25	1	Pressure Test Adapter
 0000160075	4328619R1	1	Tool Instruction

## Instructions

**NOTE: Please reference International® Service Portal<sup>SM</sup> regarding any possible revisions to this document.**

1. Park vehicle on a flat surface.
2. Shift transmission into Park or Neutral and set parking brake.
3. Turn ignition to Key OFF position.
4. Install wheel chocks.
5. Locate and access exhaust system; refer to appropriate Service Manual for detailed instructions.
6. Perform procedure; refer to appropriate Service Manual for detailed instructions.
7. Remove wheel chocks.

## Care and Maintenance

- Keep tools clean and free of contaminants
- Replace any damaged components

## Contact Information

If you would like to order additional tools or need replacement parts, please refer to the Navistar Service Tool Catalog. If you have questions, concerns, or feedback, please contact Navistar Service Tool Support Center:

- Submit a Service Tool iKNow Case File.
- Phone: 800-365-0088 (toll free).