

# **Tool Instruction Engine Lift Bracket Set**

4328621R1

Tool Number: J-36857



0000433624

Figure 1. J-36857 — Engine Lift Bracket Set

#### Purpose

J-36857 is an essential tool used to assist when supporting and lifting the engine.

### Application(s)

International<sup>®</sup> CV<sup>™</sup> Series

Additional Engine / Vehicle Applications May Apply

Read all safety instructions in the "Safety Information" section of the appropriate Engine Service or Diagnostic Manual. Follow all warnings, cautions, and notes. ©2018 Navistar, Inc. All rights reserved. All marks are trademarks of their respective owners.

1

## Application(s) (cont.)

**GOVERNMENT REGULATION:** Engine fluids (oil, fuel, and coolant) may be a hazard to human health and the environment. Handle all fluids and other contaminated materials (such as filters or rags) in accordance with applicable regulations. Recycle or dispose of engine fluids, filters, and other contaminated materials according to applicable regulations.

**WARNING:** To prevent personal injury and / or death, read all safety instructions in the "Safety Information" section of the *Engine Service Manual* or *Engine Diagnostic Manual*.

WARNING: To prevent property damage, personal injury, and / or death, park vehicle on hard flat surface, turn the engine off, set the parking brake, and install wheel chocks to prevent the vehicle from moving in either direction.

WARNING: To prevent personal injury and / or death, always wear safe eye protection when performing vehicle maintenance.

WARNING: To prevent property damage, personal injury, and / or death, inspect tool for wear / damage prior to use. Replace any worn or damaged components as necessary.

#### **Tool Contents**

Table 1

Image	Tool Number	Qty	Description
8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8	J-36857	1	Engine Lift Bracket Set
0000160075	4328621R1	1	Tool Instruction

#### Instructions

NOTE: Please reference International<sup>®</sup> Service Portal<sup>™</sup> regarding any possible revisions to this document.

1. Refer to appropriate Service Manual for detailed instructions.

#### **Care and Maintenance**

- Keep tools clean and free of contaminants
- Replace any damaged components

#### **Contact Information**

If you would like to order additional tools or need replacement parts, please refer to the Navistar Service Tool Catalog. If you have questions, concerns, or feedback, please contact Navistar Service Tool Support Center:

- Submit a Service Tool iKNow Case File.
- Phone: 800-365-0088 (toll free).