

# **Tool Instruction A/C Flushing Kit**

4328642R1

Tool Number: 19-000-04



0000434290

Figure 1. 19-000-04 - A/C Flushing Kit

## **Purpose**

Essential tool kit used to flush the A/C system on the International® CV<sup>TM</sup> truck.

### Application(s)

2018 International® CV™ Series.

Additional Vehicle / Engine Applications May Apply.

GOVERNMENT REGULATION: Engine fluids (oil, fuel, and coolant) may be a hazard to human health and the environment. Handle all fluids and other contaminated materials (such as filters or rags) in accordance with applicable regulations. Recycle or dispose of engine fluids, filters, and other contaminated materials according to applicable regulations.

WARNING: To prevent personal injury and / or death, read all safety instructions in the "Safety Information" section of the Engine Service Manual or Engine Diagnostic Manual.

WARNING: To prevent property damage, personal injury, and / or death, park vehicle on hard flat surface, turn the engine off, set the parking brake, and install wheel chocks to prevent the vehicle from moving in either direction.

WARNING: To prevent personal injury and / or death, always wear safe eye protection when performing vehicle maintenance.

WARNING: To prevent property damage, personal injury, and / or death, inspect tool for wear / damage prior to use. Replace any worn or damaged components as necessary.

#### **Tool Contents**

#### Table 1

Image	Tool Number	Qty	Description
0000434292	19-000-04	1	A/C Flushing Kit (Kit includes components below)
0000434318	19-094-05	1	Evaporator Adapter Tool (Included in Kit)

# **Tool Contents (cont.)**

Table 1. (cont.)

Image	Tool Number	Qty	Description
0000434322	19-632-05	1	Line Loop Tool (Included in Kit)
0000434326	19-632-06	1	Line Adapter Tool (Included in Kit)
0000434329	19-632-07	1	Line Loop Tool (Included in Kit)
0000434314	19-043-03	1	Condenser Adapter Tool (Included in Kit)
NAVISTAR 0000160075	4328642R1	1	Tool Instruction (Included in Kit)

#### Instructions

NOTE: Please reference International® Service Portal<sup>sм</sup> regarding any possible revisions to this document.

- Park vehicle on flat surface.
- 2. Shift transmission into Park or Neutral and set parking brake.
- 3. Turn ignition to Key OFF position.
- 4. Install wheel chocks.
- 5. Perform procedure; refer to appropriate Service Manual for detailed instructions.
- 6. Remove wheel chocks.

#### **Care and Maintenance**

- · Keep tools clean and free of contaminants
- · Replace any damaged components

#### **Contact Information**

If you would like to order additional tools or need replacement parts, please refer to the Navistar Service Tool Catalog. If you have questions, concerns, or feedback, please contact Navistar Service Tool Support Center:

- · Submit a Service Tool iKNow Case File.
- Phone: 800-365-0088 (toll free).