

Tool Instruction O-RING REPLACEMENT KIT

4328410R1

Tool Number: KL20030-2-GK

Purpose

O-ring Replacement Kit for KL20030-2 component of KL20030NAV EGR Leak Detection Kit.

Application(s)

KL20030NAV EGR Leak Detection Kit

WARNING: To prevent property damage, personal injury, and / or death, read all safety instructions in the "Safety Information" section of the *Engine Service Manual* or *Engine Diagnostic Manual*.

WARNING: To prevent property damage, personal injury, and / or death, park vehicle on hard flat surface, turn the engine off, set the parking brake, and install wheel chocks to prevent the vehicle from moving in either direction.

WARNING: To prevent personal injury and / or death, always wear safe eye protection when performing vehicle maintenance.

Tool Contents

Table 1

Image	Tool Number	Qty	Description
0000405670	KL20020-3-5	2	O-Ring
0000405666	KL20020-2-6	2	Small O-Ring
NAVISTAR Southernoise 0000160075	4328410R1	1	Tool Instruction

Instructions

NOTE: Please reference International[®] Service Portal[™] regarding any possible revisions to this document.

Instructions (cont.)




Figure 1. O-Ring Locations

- 1. Large O-ring (2)
- 2. Small O-ring (2)
- 1. Remove worn O-rings (Figure 1, Items 1 & 2).
- 2. Obtain kit-supplied O-rings and lubricate with oil.
- 3. Install kit-supplied O-rings.

Contact Information

If you would like to order additional tools or need replacement parts, please refer to the Navistar Service Tool Catalog. If you have questions, concerns, or feedback, please contact Navistar Service Tool Support Center:

- Submit a Service Tool iKNow Case File.
- Phone: 800-365-0088 (toll free).