

Tool Instruction DEF Supply Module 12-way Breakout Harness

4328129R1

Tool Number: 18-909-01



0000055679

Figure 1. DEF Supply Module 12-way Breakout Harness 18-909-01.

Purpose

The DEF Supply Module 12-way Breakout Harness 18-909-01 is designed to aid in diagnosing faults within the DEF supply module circuits, which include the following:

- · DEF line pressure sensor
- DEF supply pump
- · DEF return valve
- DEF dosing unit heater

Application(s)

N13 with SCR (EPA 10) with HD-OBD

Tool Contents

Table 1

| Image | Tool Number | Qty | Description |
|------------|-------------|-----|---|
| 0000055676 | 18-909-01 | 1 | DEF Supply Module 12-way Breakout Harness |
| 0000160075 | 4328129R1 | 1 | Instruction Sheet |

Instructions

GOVERNMENT REGULATION: Engine fluids (oil, fuel, and coolant) may be a hazard to human health and the environment. Handle all fluids and other contaminated materials (such as filters and rags) in accordance with applicable regulations. Recycle or dispose of engine fluids, filters, and other contaminated materials according to applicable regulations.


WARNING: Read all safety instructions in the "Safety Information" section of the Engine Service Manual or Engine Diagnostic Manual to prevent personal injury or death.

WARNING: To prevent personal injury or death, shift transmission to park or neutral, set parking brake, and block wheels before doing diagnostic or service procedures.

WARNING: To prevent personal injury or death, remove all ground cables from negative terminal of all batteries before disconnecting or connecting electrical components. Always connect ground cables last.

WARNING: To prevent personal injury or death, do not let engine fluids stay on your skin. Clean skin and nails using hand cleaner and wash with soap and water. Wash or discard clothing and rags contaminated with engine fluids.

Instructions (cont.)



0000055678

Figure 2. Breakout Harness 18-909-01 Installation.

- 1. DEF supply module 12-way harness
- 2. Breakout Harness 18-909-01
- 3. Banana jack
- 1. Disconnect DEF supply module 12-way harness (Figure 2, Item 1).
- 2. Install Breakout Harness 18-909-01 (Figure 2, Item 2).
- 3. Using proper diagnostic procedures, test circuit.

Contact Information

If you would like to order additional tools, have questions, concerns, feedback, or need replacement parts, please contact:

Navistar Service Tool Support Center

- Submit a Service Tool iKNow case file
- Phone: 800-365-0088 (Toll Free) or 630-985-4171

4328129R1